

## Podstawowe dane techniczne / Basic technical data:

Zasilanie / Feed AC 230V 50/60Hz  
 Zasilacz / Power supply Tok  
 Źródło światła / Light source LED  
 CRI / Color rendering index CR198  
 Moc / Power 8W

## Dotyczy opraw / Applies to frames:

Proxa Move NT H145 edge.LED | 8W  
 On-Off | 3.0729  
 DALI | 3.1662  
 Switch | 3.2802  
 PhaseCut | 3.1661

Proxa Move NT 230 edge.LED | 8W  
 On-Off | 3.0730  
 DALI | 3.1664  
 Switch | 3.2803  
 PhaseCut | 3.1663

Proxa Move NT 330 edge.LED | 8W  
 On-Off | 3.0731  
 DALI | 3.1666  
 Switch | 3.2804  
 PhaseCut | 3.1665




Ten produkt zawiera źródło światła o klasie efektywności energetycznej:


This product contains a light sources of energy efficiency class:



Light source (LED only) contained in the luminaire replaceable only by a professional  
 Źródło światła (tylko LED) umieszczone w oprawie powinno być wymieniane tylko przez wykwalifikowaną osobę



Control gear contained in the luminaire replaceable only by a professional  
 Zasilacz umieszczony w oprawie powinien być wymieniany tylko przez wykwalifikowaną osobę



**UWAGA !** Nie podłączaj oprawy oświetleniowej do zasilacza LED przy włączonym zasilaniu!!! Podłączenie oprawy oświetleniowej do zasilacza przy włączonym zasilaniu grozi uszkodzeniem modułu LED i utratą gwarancji.

**NOTE !** Do not connect the lighting fixture to the LED driver with the power on !!! Connecting the lighting fitting to the LED driver with the power switched on may damage the LED module and void the warranty.

**LABRA Sp. z o.o.**

bureau@labra.pl / export@labra.pl  
 -48 500 175 552 / www.labra.pl



**1**

**2**

**3**

**4a**

**4b**

**5**

Odłącz napięcie!  
Disconnect the voltage!

**6**

**7**

Wróć do etapu 4  
Go back to step 4

**8**

**9**

**10**

Sprężyna musi pozostać w rowku.  
The spring must remain in the groove.

**11**

Włącz  
Turn On

145
230
330

2022-01-17